



**WINDSHIELD**  
**WILL FIT E-Z-GO® RXV®**  
**INSTALLATION INSTRUCTIONS MJWS2001**

**INCLUDED:**  
WINDSHIELD  
2 STRUT BRACKETS



Windshield



2 Strut Brackets

**1**

Remove plastic from all four sides of the windshield.



**2**

Now install the strut brackets as shown onto the side of the windshield. \*Repeat process on the other side.



3  
Once the strut brackets have been installed on the windshield you can attach it to your cart. Slide down the cowl.



4  
Once the base of the windshield is attached, raise the top half and clamp as shown.

**VISIT [WWW.MYMADJAX.COM](http://WWW.MYMADJAX.COM) FOR MORE  
INSTALLATION VIDEOS AND PRODUCTS**

E-Z-GO®, TXT®, RXV® are trademarks of Textron Innovations, Inc. ("Textron"). Reference to Textron's trademarks and products is only for purposes of identifying golf carts with which this Madjax product is compatible. Madjax products are aftermarket parts and are not original equipment parts. Madjax is not connected or affiliated with or sponsored by Textron.