


# STARTER GENERATOR




Ref. No.	Part Number	Description	Qty	Remarks
1	J10-81100-10-00	STARTER GEN ASSEMBLY ASSY	1	
2	J10-81150-10-00	. ARMATURE ASSEMBLY	1	
3	J10-81157-10-00	. BEARING 1 (6202 SD)	1	
4	J10-81158-10-00	. BEARING 2 (6203 SD)	1	
5	J10-81159-10-00	. HOLDER, BEARING	1	
6	J10-81175-10-00	. STOPPER 1	1	
7	J10-81110-10-00	. STATOR ASSEMBLY	1	
8	J10-81160-10-00	. FIELD COIL ASSEMBLY	1	
9	J10-81148-10-00	. SCREW	2	
10	95380-06600-00	.. NUT	4	
11	92901-06600-00	.. WASHER	2	
12	92995-06100-00	.. WASHER, SPRING	4	
13	J10-81146-10-00	. SCREW	4	
14	J10-81165-10-00	. BRKT, STARTER GEN 1 GENERATOR 1	1	
15	J10-81166-10-00	. BRACKET, STARTER GENERATOR	1	
16	J10-81147-10-00	. SCREW	2	
17	95380-06600-00	.. NUT	2	
18	92901-06600-00	.. WASHER	2	
19	92995-06100-00	.. WASHER, SPRING	4	
20	J10-81119-10-00	. BRUSH HOLDER ASSEMBLY	1	
21	J10-81111-10-00	. BRUSH	4	
22	J10-81113-10-00	. SPRING, BRUSH	4	
23	J10-81115-10-00	. WIRE, LEAD	2	
24	98580-05016-00	. SCREW, PAN HEAD	2	
25	98580-04010-00	. SCREW, PAN HEAD	4	
26	J38-81163-10-00	. KEY	1	
27	95301-14700-00	. NUT	1	

CONTINUED ON NEXT FRAME ►




# STARTER GENERATOR



Ref. No.	Part Number	Description	Qty	Remarks
28	92901-14100-00	. WASHER, SPRING	1	
29	98501-05018-00	. SCREW, PAN HEAD	3	
30	J10-81129-10-00	. COVER, BRUSH	3	
31	J10-81129-10-00	. COVER, BRUSH	1	
32	J10-81145-10-00	. SCREW	2	
33	92901-06600-00	. WASHER	2	
34	92995-06100-00	. WASHER, SPRING	2	
35	92990-05100-00	. WASHER, SPRING	2	
36	92901-04100-00	. WASHER, SPRING	4	



# STARTER PULLEY



Ref. No.	Part Number	Description	Qty	Remarks
1	J17-87183-00-00	INSULATOR, GEN .....	1	
2	98580-05010-00	SCREW, PAN HEAD .....	4	
3	92990-05100-00	WASHER, SPRING .....	4	
4	J10-81161-01-00	PULLEY .....	1	
5	J10-87172-00-00	FAN, GENERATOR .....	1	
6	98580-06020-00	SCREW .....	2	
7	92995-06100-00	WASHER, SPRING .....	2	
8	92901-06600-00	. WASHER .....	2	
9	J10-81173-00-XX	BELT .....	1	
10	90105-08326-00	BOLT, WASHER BASED .....	1	
11	90387-08683-00	COLLAR .....	1	
	J10-21647-00-00	BAND 0 1 .....	1	877~
12	92990-08200-00	WASHER, PLAIN .....	2	
13	92990-08100-00	WASHER .....	2	
14	95333-08600-00	. NUT .....	1	
15	90387-08687-00	COLLAR .....	2	
16	J10-81170-00-00	TENSIONER ASSEMBLY .....	1	
17	97313-08030-00	BOLT, HEXAGON .....	1	
18	90201-08107-00	WASHER, PLATE .....	2	
19	92990-08100-00	WASHER .....	1	
20	95333-08600-00	NUT .....	1	
21	97313-08020-00	BOLT, HEXAGON .....	1	
22	92990-08100-00	WASHER .....	1	
23	90201-08107-00	WASHER, PLATE .....	1	

